



URBAN ADVANTAGE

T A C T I C A L

S Y S T E M S

Urban Developers & Assoc. LLC
P.O. Box 1615
Blaine, WA 98231
PHONE (360) 384-3585
www.urbandvantage.net

UNLOAD FIREARM

How to make firearm safe

1. Finger off trigger
2. Point firearm in a safe direction
3. Remove the magazine
4. Lock the slide to the rear
5. Check magazine well and chamber twice to insure it's empty
(PHYSICALLY AND VISUALLY)

REMOVE ALL AMMUNITION FROM ROOM

Installing the S.P.R.S.

1. Remove slide release pin from pistol
2. Place URBAN ADVANTAGE extended pin into hole until it is flush on the mounting side of firearm.
3. Position S.P.R.S. so the fastening pin and hole line up then push and install the elongated slide stop pin assembly all the way.
4. Set tension with set screw on trigger guard to take out any movement between the S.P.R.S. and the Frame of your pistol.
(Note: do not over tighten set screw it may cause damage to the S.P.R.S. or your firearms trigger guard.)
5. Ensure the S.P.R.S. is properly aligned on the firearm before use.

(Note: if slide will not go into battery S.P.R.S. may be over tightened loosen set screw on trigger guard and check if it solves the problem. When set screw is properly adjusted apply lock-tite)

(Note: Some pistols with modified barrel lock-up links may require reinstalling factory link to achieve proper barrel lock-up and functionality.)

Purchaser and/or user agrees to hold **Urban Advantage** harmless for all damage to any person or property, by use of these products in an unlawful manner, or that which is inconsistent with stated use or specification, or otherwise not recommended by the manufacturer.